



Liune

SURFACE
SLIDING DOOR



INSTALLATION INSTRUCTIONS | SOLID DOOR

TABLE OF CONTENTS

ACCESSORIES 3

THE WALL 4

INSTALL SLIDING TRACK 5-6

INSTALL HANGING ROLLERS AND DOOR STOPPER 7

INSTALL DOOR IN SLIDING TRACK 8

INSTALL DOOR GUIDE 9-10


INSTALL END PLATES 11

ACCESSORIES


Needed tools:
power screwdriver and level!




1.




DOOR STOPPERS
2 pcs
2.




HANGING ROLLERS
2 pcs
3.




DOOR GUIDES
1 pc
4.




END PLATES
2 pcs
5.




SCREWS
6 pcs
6.



DOOR GUIDE
SCREWS 4,3 x 16
4 pcs
7.




WALL BRACKET
SCREWS 3,6 x 40
10-16 pcs
8.



OPEN END WRENCH
1 pc

THE WALL

1a Make sure that the wall is unbroken, straight and finished.



1 Make sure that the wall is suitable for installation of the sliding track.

INSTALL SLIDING TRACK



7. WALL BRACKET SCREWS 3,6 x 40




2 Follow the given measurements. Use the level to check the installation of the sliding track.

INSTALL SLIDING TRACK



7. WALL BRACKET SCREWS 3,6 x 40




3

Install the sliding track on the wall surface by using the included wall bracket screws.


INSTALL HANGING ROLLERS AND DOOR STOPPER



1. DOOR STOPPER



2. HANGING ROLLERS



4


Install the hanging rollers and the door stoppers in the sliding rail.

INSTALL DOOR
IN SLIDING TRACK



8. OPEN END WRENCH

5a Adjust the door height.
Tighten the fixing nuts.





DOORWAY	DOOR width	DOOR height	DOOR extra high
Li07	780	2135	2335
Li08	880	2135	2335
Li09	980	2135	2335
Li10	1080	2135	2335
Li011	1180	2135	2335
Li012	1280	2135	2335
Li013	1380	2135	2335
Li014	1480	2135	2335

INSTALL DOOR
GUIDE

5 Hang up the door leaf on the hanging rollers. The hanger plate, which is attached on top of the door leaf, is placed between the washer and the flange nut of the hanging rollers.

6 Check the the distance between the door leaf and the wall is equal up and down when you install the door guide.



INSTALL DOOR GUIDE




3. DOOR GUIDE



6. DOOR GUIDE SCREW
4,3 x 16



Casings and floor moldings are not included in the delivery.



7

Check that the distance between the door leaf and the wall is equal up and down to make sure that the door guide is installed in the correct position.

INSTALL END PLATES



4. END PLATE




5. SCREWS



1



2



8

1. Click the end plate to the sliding rail.
2. Attach the end plates to the covering plate with the included screws.



Liune Door Sales Office:

Aulis Lundell Oy
Tel. +358 207 341 400
sales@liune.fi
www.liune.fi/en

LIUNE
NORDIC
DESIGN



EPD No. RTS_38_19
LIUNE -door system
with glass/MDF door
www.liune.fi/epd



Aulis Lundell Oy's production is certified by
the ISO9001 –quality management system.
The certification has been withheld since 2004.



Business environmentally certified since 2004.
Liune Door is patented No FI7139 16.11.2005



**TO BORROW THE PICTURES IN THIS INSTRUCTION MANUAL IS ALLOWED TO
AULIS LUNDELL OY'S CUSTOMERS AND PARTNERS IF THE SOURCE IS MENTIONED.
WE RESERVE THE RIGHT TO MAKE CHANGES TO THE PICTURES AND
THE ACCOMPANING TEXTS.**



www.liune.fi/en

